

DC0-200^{Q&As}

Certified Server Professional Exam

Pass Dell DC0-200 Exam with 100% Guarantee

Free Download Real Questions & Answers **PDF** and **VCE** file from:

https://www.pass2lead.com/dc0-200.html

100% Passing Guarantee 100% Money Back Assurance

Following Questions and Answers are all new published by Dell Official Exam Center

Instant Download After Purchase

100% Money Back Guarantee

😳 365 Days Free Update

800,000+ Satisfied Customers





QUESTION 1

What should you do to clear NVRAM and force the system to reset its configuration data?

A. NVRAM cannot be cleared once it has been set by an administrator.

B. boot to the Dell Server Assistant CD first

C. in the System Setup utility, activate the Num Lock, Caps Lock, and Scroll Lock lights on the keyboard, then press Alt-E

D. press F10 when prompted at startup

Correct Answer: C

QUESTION 2

You need to install Intel NIC teaming for Windows 2000 and you do not have access to the Internet. From what two sources can you obtain the PROSet software? (Choose two.)

- A. Dell Network Applications CD
- B. Dell Server Assistant (DSA)
- C. Windows 2000 Installation CD
- D. Intel Network Drivers CD

Correct Answer: BD

QUESTION 3

What is a dynamic volume as defined by Array Manager?

- A. a logical volume that can be created from a dynamic disk
- B. a volume that resides in the extended partition of a basic disk
- C. a logical volume created from portions of one or more basic disks
- D. a physical disk that has been marked as dynamic by Array Manager

Correct Answer: A

QUESTION 4

How many DIMMs are required for the minimum memory configuration on a server with four-way interleaving memory addressing?



- A. 4
- B. 1
- C. 8
- D. 2
- Correct Answer: A

QUESTION 5

OpenManage Server Administrator can determine the status of which two server components? (Choose two.)

- A. memory
- B. network activity
- C. processor load
- D. disk utilization
- E. fans
- Correct Answer: AE

DC0-200 PDF Dumps

DC0-200 VCE Dumps

DC0-200 Braindumps